

2004-2006 Pontiac GTO

Key programming

Key FOB Transmitter Programming

You can't program the remote without being able to put it in the ignition and turn it to the different positions. Have the key cut by a locksmith and use the procedures below to program the remote. A locksmith that has the capability/equipment to cut center cut keys can do it.

Transmitter Programming

The transmitter may not communicate with the receiver if any of the following situations occurs:

- The transmitter battery wears down.
- The transmitter key has been replaced.
- The Body Control Module (BCM) has been replaced.

Perform the synchronizing procedure if the transmitter does not communicate with the receiver. If the transmitter and/or receiver are replaced, perform the following programming procedure:

Programming Transmitters Without Tech 2

- Turn the ignition to ON, then wait 10 minutes for the next step in the programming sequence.
- After the 10 minutes has elapsed, the car horn will chirp once. Turn the ignition switch to the OFF position within 5 minutes after the horn has sounded, then to the ON position within 5 seconds after switching it OFF.
- Leave the key to the ON position for 10 minutes. After the 10 minutes has elapsed, the car horn will chirp twice. Turn the ignition switch to the OFF position within 5 minutes after the horn has sounded, then to the ON position within 5 seconds after switching it OFF.
- Leave the key to the ON position for 10 minutes. After the 10 minutes has elapsed, the car horn will chirp 3 times.
- Verify that the security indicator in the instrument cluster has stopped flashing and attempt to start the vehicle.
- Turn the ignition to OFF and remove the key from the ignition switch.
- Move approximately 3 meters (10 ft) away from the vehicle and test the transmitter functions to validate that the transmitter has been programmed successfully.